




MOUNTING GUIDE

P-620 PROXIMITY READER

Shown Actual Size

To use as a template for mounting on flat surfaces, print page at 100% (Letter)



FRONT VIEW

Farpointe Data, Inc.
2195 Zanker Road
San Jose, CA 95131 USA
Office: +1-408-731-8700
Fax: +1-408-731-8705
support@farpointedata.com
www.farpointedata.com