




MOUNTING GUIDE

P-405 PROXIMITY READER

Shown Actual Size

To use as a template for mounting on flat surfaces, print page at 100% (Letter)



Be sure to use appropriate tools and proper safety equipment during installation.
Farpointe Data reserves the right to change specifications without notice.
© 2017 Farpointe Data, Inc. All rights reserved.

Farpointe Data, Inc.
1376 Borregas Avenue
Sunnyvale, CA 94089-1004 USA
Office: +1-408-731-8700
Fax: +1-408-731-8705
support@farpointedata.com
www.farpointedata.com